

## **RADIOACTIVE SPILL**

- Stop what you are doing and stay in the immediate area.
- Presume that you are contaminated. Do not make unnecessary moves in order to avoid spreading the contamination. If possible, check your skin for contamination.
- Inform others in the immediate area of the spill.
- Contact the Radiation Safety Office at 203-785-3555. After hours, call 911 from any Yale phone.
- Localize the spilled material by placing absorbent material on the spill. Be sure to wear gloves.
- Label the area as contaminated.
- Prohibit others from entering or leaving the area.